



RShell Reference Manual

Version 7.3

Copyright © 2012 - 2020 Impinj, Inc. All rights reserved

<http://www.impinj.com>

Impinj, Octane, Speedway, xSpan and xArray are either registered trademarks or trademarks of Impinj, Inc. Visit www.impinj.com/trademarks for additional information about Impinj trademarks.

Contents

1	Introduction	4
2	Document Conventions	5
2.1	Syntax	5
2.2	Examples	5
3	Overview	6
3.1	Help	7
3.2	Response Format	9
3.3	Compatibility	10
4	Command Reference	12
4.1	Reboot Command	12
4.2	Config Command	12
4.2.1	Config Access Command	12
4.2.2	Config Image Command	13
4.2.3	Config Logging Command	17
4.2.4	Config Network Command	20
4.2.5	Config RFID Menu	35
4.2.6	Config SNMP Command	40
4.2.7	Config System Menu	46
4.2.8	Config Feature Menu	49
4.3	Show Command	51
4.3.1	Show Image Menu	51
4.3.2	Show Logging Menu	59
4.3.3	Show Network Menu	60
4.3.4	Show RFID Menu	72
4.3.5	Show SNMP Menu	77

4.3.6	Show System Menu	78
4.3.7	Show Feature Menu	83
4.3.8	Show Anthub Command	84
5	Revision History	85
6	Notices	88

1 Introduction

The Command Line Interface (CLI) for the Impinj Speedway Reader, the Impinj R700 RAIN RFID Reader, and the xArray and xSpan Gateways is called RShell. RShell can be accessed after you log in via a serial or SSH connection. You can use the CLI to configure, maintain, and query the status of an RFID Reader.

2 Document Conventions

This document covers the Impinj Octane 7.3 and Impinj R700 RAIN RFID Reader 7.3 software releases. The term “Reader” is used to refer to the Impinj R700 RAIN RFID Reader, the Impinj Speedway Reader, and the xArray and xSpan Gateways.

2.1 Syntax

The following markings are used throughout this document:

[] - optional

() - grouping

| - either

<> - placeholder

Literal (reduced size +bold) - a literal term

Syntax example:

Usage: `command1` [`<paramA>` (`on|off`)]

The syntax example indicates that `command1` had optional parameters. If `paramA` is specified, it must be followed by ‘on’ or ‘off’.

2.2 Examples

Code examples are provided throughout this reference manual. To help differentiate from descriptive text, the code is shown in a fixed font or using double quotes.

In addition, the input is shown in bold in the examples. In the following example, “help help” is typed, the remainder is the Reader’s response.

```
> help help
```

```
help - Displays this help message.
```

```
Usage: help [<subcommand>]
```

3 Overview

You can navigate to any of the RShell menus simply by entering the menu name at the RShell prompt, as shown below:

```
> show network
show network >
```

For machine execution, all RShell commands can be called from the root menu. For example:

```
> show network
show network> dns
```

is equivalent to:

```
> show network dns
```

All commands return data in a well-defined format.

```
show network > dns
```

```
Status='0,Success'
Domain1Dynamic='impinj.com'
Server1Dynamic='10.10.4.11'
Server2Dynamic='10.0.4.10'
```

For all menus, the **exit** command or simply **.'** will return you to the previous menu's context. To exit RShell and terminate your session, the **exit** command must be executed from the root menu (the period only will not suffice):

```
show network> exit
> show
show > .
> .
>
```

3.1 Help

For all menus, the "**help**" command or simply the question mark (?) opens a list of all active menu commands available from the Reader, as well as the submenus that can be accessed from the active menu.

```
> help
```

Commands:

```
reboot - Reboot the reader.  
exit - Exit RShell.  
help - Display this help message.  
? - Display this help message.
```

Submenus:

```
config - Submenu of configuration commands.  
show - Submenu of elements that may have their configuration or  
status shown.
```

Menu navigation and the **help** keyword or question mark (?) can be combined on the same line to list all the commands available for that menu. For example:

```
> show help
```

or

```
> show ?
```

Commands:

```
exit - Exit this submenu and return to the parent menu.  
help - Display this help message.  
. - Exit this submenu and return to the parent menu.  
? - Display this help message.
```

Submenus:

```
image - Image status commands.  
logging - Logging status commands.  
network - Network status commands.  
rfid - RFID status commands.
```

snmp - SNMP status commands.
system - System status commands.
feature - Feature status commands.
anthub - Antenna Hub status commands

For all menus, entering the **help** command or question mark (?) prior to a command or menu returns a short description of the command and the syntax for its usage (if any). For example:

```
> ? show
```

show - Submenu of elements that may have their configuration or status shown.

Usage: show [<subcommand> ...]

or

```
> ? show system platform
```

platform - Display generic platform statistics.

Usage: show system platform

Entering the question mark (?) between a menu and sub-menu/command returns the usage for the items following the "?" at the lowest level. In the example below, **image** is a menu that contains commands of its own. Entering **show ? image** opens a usage help menu that indicates that subcommands are necessary. If one of those subcommands is entered (**show ? image metafile**), the detailed usage is given.

```
> show ? image
```

image - Submenu of image status commands.

Usage: image [<subcommand> ...]

```
> show ? image metafile
```

metafile - Displays information about the current image upgrade metafile.

Usage: image metafile

3.2 Response Format

The first line of every command response has the following format.

Status='errorCode,errorString'

The *errorCode* is a numeric value and *errorString* is a human-readable error code. The error codes are defined in Table 3.1.

Table 3.1: General Status Codes*

Error Code	Error String	Description
0	Success	The command completed successfully.
1	Invalid-Command	Command could not be parsed and identified as an interface supported command.
2	Invalid-Command-Parameter	One or more parameter types were unrecognized for this command.
3	Invalid-Parameter-Value	One or more parameter values were illegal or out-of-range for this command.
4	Parameter-Dependency-Error	Parameter value was invalid in combination with other parameters or values.
5	Incomplete-Parameter-List	The parameter list was incompletely specified and the command cannot be executed.
6	System-Resource-Limit	Command could not be executed because of a resource limit in the system. For example: the Reader could not add a fourth trap receiver because the device only supports three.
7	Unsupported-Command	Reserved for Future commands.
8	Permission-Denied	User does not have permission to access this command.
9	Previous-Command-In-Progress	The command was rejected because a previous command is still in progress and the new command could not be processed.
10	Command-Being-Processed	The command cannot be finished right away: It is being processed.
11	Failure	The command failed internally for an unexpected reason.

Error Code	Error String	Description
12	Provider-Unavailable	The process responsible for handling the requested operation is currently unavailable and therefore cannot complete the requested operation.
13	Status-Was-Lost	The command failed internally and produced an invalid result.
14	Success-Reboot-Required	The command completed successfully and the Reader requires a reboot before any changes take effect.
15	Incompatible-With-Enabled-Feature	The feature is not compatible with another feature which is already enabled.

A sample error parameter string shows below with the command deliberately misspelled:

```
> config foobar
```

```
Status='1,Invalid-Command'
```

When a command action generates results, the results follow the status line, one parameter per line in the following format:

```
ParameterName='value'  
ParameterName='value'  
...  
ParameterName='value'
```

The specific response parameters for each command are detailed in Section 4. Many commands display only a relevant subset of their possible parameters. In these cases, failure to find the parameter would not be a protocol error. Some command responses are transient, meaning that their value will change as an activity progresses.

3.3 Compatibility

The RShell CLI is designed to be both a machine interface and a human interface. Impinj strives to maintain backward compatibility within the Speedway and xArray/xSpan product lines. For the new R700 product line, existing command inputs and outputs should be relatively stable.

To ensure future compatibility, applications designed to interpret the CLI responses should ignore unrecognized parameters and should not read any significance into the order of the parameters. This allows for new result parameters to be displayed without forcing a change on the interpreting application.

For example, in the firmware version Octane 7.3, the **show network summary** command provides the following response:

```
> show network summary
```

```
Status='0,Success'  
PrimaryInterface='eth:eth0'  
ActiveInterface='eth:eth0'  
Hostname='SpeedwayR-10-46-B2'  
connectionStatus='Connected'  
ipAddressMode='Dynamic'  
ipAddress='10.0.11.27'  
ipMask='255.255.0.0'  
gatewayAddress='10.0.0.20'  
broadcastAddress='10.0.255.255'  
MACAddress='00:16:25:10:46:B2'  
HTTPService='active'
```

4 Command Reference

This section describes all the commands available within the RShell command line interface and the possible responses.

4.1 Reboot Command

The **reboot** command instructs the Reader to reboot. This command would typically be used after a manual upgrade of the Reader’s firmware or application software. The **reboot** command is only available from the root menu.

4.2 Config Command

The **config** command has several submenus, shown in the following table, all of which are described in the following sections.

Table 4.1: Config Command Parameters

Command	Description
access	Submenu of access configuration commands.
image	Submenu of image and upgrade configuration commands.
logging	Submenu of logging configuration commands.
network	Submenu of network configuration commands.
rfid	Submenu of RFID configuration commands.
snmp	Submenu of SNMP configuration commands.
system	Submenu of system configuration commands.
feature	Submenu of feature configuration commands.

4.2.1 Config Access Command

The **config access mypasswd** command changes the password for the logged-in user. “Root” is the only user login defined for the Reader. The Reader default password is set to ‘impinj’. Other Reader types might use alternative default passwords.

The user account name and password are used to access the command line interface via serial and ssh. The **config access** submenus and the **config access mypasswd** command arguments are described in the following two tables.

Table 4.2: Config Access Command Options

Command Parameters	Description
mypasswd <old password> <new password>	Change the password of the logged-in user from the old (current) password to a new password.

Table 4.3: Config Access Command Parameters

Argument	Options	Format	Description
mypasswd	<old password> <new password>	string string	Password to set as account's active password (use printable characters only). Passwords up to 20 characters in length have been tested. Passwords entered on the command line are clear text.

Usage: **config access mypasswd <old password> <new password>**

4.2.2 Config Image Command

The **config image** command provides options for image and upgrade configurations. A detailed explanation of how to upgrade images is given in the *Firmware Upgrade Reference Manual*.

Table 4.4: Config Image Command Parameters

The command parameters for the **config image** command are shown in the following table.

Command	Description
default	Restore the image to the default configuration.
fallback	Fall back to the previous image (if valid).
removecap	Remove the Custom Application Partition (CAP).
metafile	Perform an upgrade using a metafile from the specified URI.
retrievemode	Configure the mode used to upgrade the image.
upgrade	Perform an upgrade using the image file at the specified URI.

Config Image Default Command

The **config image default** command restores the configuration to the default settings. When complete, the command is automatically followed by a reboot. The custom application (if any) is notified after the reboot, so that configuration specific to the custom application (if any) can also be restored to the defaults. This command takes no parameters.

During restoration to the configuration defaults, the **show image summary** command reports the

UpgradeStatus as 'WaitingForCDR'. When this command is executed, the **metafile retrieve-mode** is set to **manual**, which cancels any previously scheduled periodic upgrade. When the Reader subsequently boots, the Reader will be running default configuration for the same system version as the system from which it performed the configuration default restore.

If the Reader is in the **auto** upgrade mode when the **config image default** command is issued, it is possible that the Reader could be retrieving the metafile or performing an upgrade at the same time. In this case, this command may return "Previous-Command-In-Progress." If this occurs, wait for the metafile to be retrieved or the upgrade to complete before executing this command again. A short wait allows the command in progress to complete.

Usage: **config image default**

Config Image Fallback Command

The **config image fallback** command is used to revert back to the previous image. The successful processing of this command is followed by an automatic reboot. This command accepts no parameters.

If there is no valid previous image available to fall back to, "Permission-Denied" is the command response. In the meantime, the Reader operates normally, except that all of the **config image** commands will be rejected with the reason "Current Image Invalidated." In addition, if **retrieve-mode** is set to **auto**, the fallback command will cancel any previously scheduled periodic upgrades. When the Reader is rebooted, the previous image will be running.

If the Reader is in auto mode during execution of the **config image fallback** command, it is possible that the Reader could be retrieving the metafile or performing an upgrade at the same time. If this is the case, this command might return "Previous-Command-In-Progress."

A fallback uses all the old configuration settings, including the upgrade metafile settings as if the upgrade to the newer image was never performed. This may trigger an immediate upgrade. If the URI of the old metafile is known and an immediate upgrade is not desired, the user should remove or rename the old metafile before performing a fallback.

Config Image RemoveCAP Command

The **config image removecap** command is used to remove the Custom Application Partition (CAP). The successful processing of this command follows with an automatic reboot. This command takes no parameters.

The effect of this command can be reversed. In other words the CAP can be restored by issuing a **config image fallback** command. Performing the **config image removecap** twice ensures that the removed CAP cannot be restored.

If the Reader is in **auto** mode during execution of this command, it is possible that the Reader could be retrieving the metafile or performing an upgrade at the same time. If this is the case, this command might return "Previous-Command-In-Progress."

Config Image Metafile Command

This command takes the Universal Resource Identifier (URI) of the upgrade configuration metafile as its parameter. It commands the Reader to perform upgrades based on the information in the metafile identified by the URI.

Usage: config image metafile <URI>

Upon receiving this command, the Reader updates its local upgrade configuration URI. It then retrieves the (new) upgrade configuration metafile, and performs the upgrade in accordance with the metafile. If the upgrade is successful, the way the new image is activated depends on the commit-mode specified in the metafile. For more information, see the *Firmware Upgrade Reference Manual*.

If the Reader is in auto mode during the execution of this command, it is possible that the Reader could be retrieving the metafile or performing an upgrade at the same time. If this is the case, this command will return “Previous-Command-In-Progress.”

Config Image RetrieveMode Command

This command sets the Reader’s **metafile retrieve** mode and can also set the retrieval period if the mode is set to **auto**, as described in the following table. When the retrieve-mode is set to **manual**, the Reader will take no upgrade actions. To perform an upgrade in manual mode the user must issue a **config image upgrade** command, which directly downloads an upgrade image.

Table 4.5: Config Image RetrieveMode Command Parameters

Command	Argument	Format	Description
retrievemode	manual	enum	In manual mode the user must specify a new metafile URI or run the config image upgrade command an upgrade.

Command	Argument	Format	Description
	Auto <period>	enum integer	In auto mode, the Reader periodically retrieves the metafile from the most recent metafile URI at the rate specified by the <period> in minutes. The retrieve period is used only until the Reader retrieves a valid metafile, at which time the retrieve period contained in the metafile is adopted.

Usage: config image retrievemode manual

Usage: config image retrievemode auto <period>

<period> is the duration between successive retrievals of the metafile (in minutes) from the most recently specified URI.

If this command results in a change from **manual** to **auto**, or a change of **retrieve-period** while the current mode is **auto**, the Reader immediately attempts to download a new upgrade configuration metafile using its current metafile URI.

Config Image Upgrade Command

This command is used to instruct the Reader to directly download an upgrade image file and perform an immediate upgrade. Upgrade image files are stored on a file server and are retrieved by the Reader from the location identified by the URI.

Usage: config image upgrade <URI>

Upon receiving this command, the Reader downloads the image file and, if the file is valid and eligible, performs the upgrade. When this command is used, the upgrade will always be performed, even if the upgrade version matches the current version. If the upgrade is successful, the new image is not activated until the user reboots the system.

If the Reader is in **auto** mode during the execution of this command, it is possible that the Reader could be retrieving the metafile or performing an upgrade at the same time. In this case, the command might return “Previous-Command-In-Progress.”

Note: This command does not change the Reader's upgrade configuration URI, but it sets the retrieve-mode to **manual**. This means that the Reader will not periodically retrieve the upgrade configuration metafile until the retrieve-mode is reset to auto.

4.2.3 Config Logging Command

The **config logging** commands provide configuration options for the storage and forwarding of logged events. Logged events are forwarded using the standard Syslog protocol to a remote Syslog server. Internally the logged events are stored in the Reader's file system, accumulating and persisting across reboots. All logged events have an associated severity level. Only events of severity greater than or equal to the user configured level are retained. Logs are classified into management, rfid, and system categories.

The user log severity can be set to one of eight levels in decreasing order from most severe to least severe: emergency, alert, critical, error, warning, notice, info, and debug. For example, if the log level is set to alert, then only logs classified as emergency or alert are processed.

Regardless of how the user configures the log settings, all error (and higher severity) logs in all categories are retained in an error log independent of the user controlled 'application' log.

Figure 4.1 illustrates a configuration where the Reader management category of logs is set to critical (and above), the RFID related logs are set to warning (and above), and the system logs are set to alert (and above).




Figure 4.1 Severity Level Logging Categories

The command parameters for the **config logging** command are shown in the following table. The command sets the logging level for a log category to one of a set of pre-defined severity levels.

Table 4.6: Config Logging Command Parameters

Argument	Option	Format	Description
add	<syslog server>	address	Add a new Syslog server with given address or hostname.
clear			Clear the contents of the application log.
del	<syslog server>	address	Delete a Syslog server with given address or hostname.
delall			Delete all listed Syslog servers.
management	emergency alert rfid system	critical error warning notice info debug	enum Configures the level at and above which logs are retained and forwarded. Listed in decreasing order of severity. The default logging level in all cases is warning level.

Note: You can add up to six syslog servers.

The logging categories are mapped to the following syslog facilities:

Table 4.7: Logging categories mapped to syslog facilities

Category	syslog facility	Description
management	LOG_LOCAL0	Reserved for local use
	LOG_AUTH	Security/authorization messages
	LOG_AUTHPRIV	Security/authorization messages (private)
system	LOG_LOCAL1	Reserved for local use
	LOG_CRON	Clock daemon (cron and at)
	LOG_DAEMON	System daemons without separate facility value
	LOG_LPR	Line printer subsystem
	LOG_MAIL	Mail subsystem
	LOG_NEWS	USENET news subsystem
	LOG_SYSLOG	Messages generated internally by syslogd
	LOG_USER	Generic user-level messages (default)
	LOG_UUCP	UUCP subsystem
rfid	LOG_LOCAL2	Reserved for local use (RFID related)

These events can be viewed via the **show logging** command.

Usage for the **config logging** command is shown below:

```
Usage: config logging <category> <level>
<category> is (management|rfid|system)
<level> is (emergency|alert|critical|error|warning|notice|info|debug)
```

Usage: config logging add <server name>

Usage: config logging clear

Usage: config logging del <server name>

Usage: config logging delall

An example of commands that clear the internal log file, configure RFID logging level to ‘warning’ (and above), and add a Syslog server located at 10.0.10.37 are shown below:

```
> config logging clear
Status='0,Success'
> config logging rfid warning
Status='0,Success'
> config logging add 10.0.10.37
Status='0,Success'
```

4.2.4 Config Network Command

The **config network** menu allows the user to administer and manually provision the network settings for the Reader. The config network command parameters are shown in the following table.

Table 4.8: Config Network Command Parameters

Command	Description
hostname	Set the Reader’s network hostname.
mdns	Configures the mDNS service to either be enabled or disabled.
wlan	Submenu for WLAN specific configuration commands.
dns	Submenu of DNS-specific configuration commands.
interface	Submenu of network interface configuration commands.
ip	Submenu of IP address and configuration commands.
ntp	Submenu of NTP-specific configuration commands.
http	Submenu for HTTP specific commands
https	Submenu for HTTPS specific commands
ftp	Submenu for FTP-specific commands
ssh	Submenu for SSH-specific commands
portsecurity	Submenu for Port Security specific commands
sftp	Submenu for SFTP specific commands
lldp	Submenu of LLDP specific configuration commands.

Config Network Hostname Command

The following table shows the **config network hostname** parameters.

Table 4.9: Config Network Hostname Command Parameters

Command	Argument	Format	Description
hostname	<host name>	string	Set the Reader hostname. If using DHCP and a hostname is returned from the DHCP server, the hostname returned from DHCP will take precedence.

The **config network hostname** command might only be available in Reader models prior to the Impinj R700 RAIN RFID Reader.

Example to change the hostname:

```
> config network hostname MySpeedwayRevolution
Status='0,Success'
```

Config Network Interface Command

Table 4.10: Config Network Interface Command Parameters

Command	Argument	Format	Description
primary	eth wlan	enum	Configure the primary interface type, i.e., the network interface that is active on bootup. Two types are supported: ethernet and wlan (WiFi).
active	eth wlan	enum	Switch the active interface to the specified type.

Example to change the active interface:

```
> config network interface active eth
Status='0,Success'
```

Config Network mDNS Command

The **config network mdns** command might only be available in Reader models prior to the Impinj R700 RAIN RFID Reader. The following table shows the **config network mdns** parameters.

Table 4.11: Config Network mDNS Command Parameters

Command	Argument	Format	Description
mdns	enable disable	enum	Configure the current state of the mDNS service. When enabled, mDNS is always active and can be used to both resolve addresses in the .local domain as well as provide resolution of the Reader within the .local domain.

An example of the command to change the state of the mDNS service:

```
> config network mDNS enable
Status='14,Success-Reboot-Required'
```

Note : reader must be rebooted after this command.

```
> config network mDNS disable
Status='0,Success'
```

Config Network DNS Command

The **config network dns** command allows the user to statically configure DNS servers. These servers are in addition to any provisioned through DHCP. The command parameters are shown in the following table.

Table 4.12: Config Network DNS Command Parameters

Command	Argument	Format	Description
add	<dns server>	<ip address>	Add a statically configured server to the list of current DNS servers. Manually configured DNS servers will be utilized after searching DNS servers returned by DHCP.
del	<dns server>	<ip address>	Delete a statically configured server from the list of current DNS servers. Servers obtained through DHCP are not available for deletion.
delall			Delete all statically configured DNS servers from the current list.

A sample command and response is shown below:

```
> config network dns add 1.2.3.4
```

Status='0,Success'

Config Network DNS Domain Command

The **config network dns domain** command allows the user to add statically configured DNS domains. These servers are in addition to any provisioned through DHCP. Command parameters are shown in the following table.

Table 4.13: Config Network DNS domain Command Parameters

Command	Argument	Format	Description
add	<domain name>	string	Add a static domain name to the list of domain names.
del	<domain name>	string	Delete a static domain name from the list of domain names.
delall			Delete all static domain names from the list of domain names.

A sample command and response is shown below:

```
> config network dns domain add mydomain.com
Status='0,Success'
```

Config Network IP Command

The **config network ip** command allows the user to statically configure IP settings or configure the Reader to use DHCP.

The reader can be configured with either a static IPv4 or static IPv6 address. IPv6 does not support broadcast addresses. If you specify a broadcast address when specifying a static IPv6 address, the broadcast address will be ignored without returning an error.

Note: The static address is immediately available. The dynamic address will remain active until the next reboot.

The command parameters are shown in the following table.

Table 4.14: Config Network IP Command Parameters

Command	Argument	Format	Description
dynamic			Configure the Reader to use DHCP parameters.

Command	Argument	Format	Description
static	<ip_address> <netmask> <gateway> <broadcast>		Configure the Reader to use statically configured IP address parameters. The following combinations of parameters are valid: <ip_address> or prefix length for IPv6 addresses (1-128) <ip_address> <gateway> <ip_address> <netmask> <gateway> <broadcast> For parameters not specified, the Reader will use default values derived from the values provided.

Examples of the commands are shown below:

Set the IP mode to dynamic:

```
> config network ip dynamic  
Status='0,Success'
```

Show the current network IP settings:

```
> show network ip summary  
Status='0,Success'  
connectionStatus='Connected'  
ipAddressMode='Dynamic'  
ipAddress='10.10.10.41'  
ipMask='255.255.0.0'  
gatewayAddress='10.10.0.1'  
broadcastAddress='10.10.255.255'
```

Set a static IPv4 address:

```
> config network ip static 192.168.20.116  
Status='0,Success'  
> show network ip summary  
Status='0,Success'  
connectionStatus='Connected'  
ipAddressMode='Static'  
ipAddress='192.168.20.116'  
ipMask='255.255.0.0'  
gatewayAddress='192.168.0.1'  
broadcastAddress='192.168.255.255'
```

Set a static IPv4 address and gateway:

```
> config network ip static 192.168.20.116 255.255.255.0 192.168.20.1  
192.168.20.255  
Status='0,Success'  
> show network ip summary  
Status='0,Success'  
connectionStatus='Connected'  
ipAddressMode='Static'  
ipAddress='192.168.20.116'  
ipMask='255.255.255.0'  
gatewayAddress='192.168.20.1'  
broadcastAddress='192.168.20.255'
```

Set a static IPv6 address:

```
> config network ip static 2600:2104:5:3:2c88:2a32:5634:1234  
Status='0,Success'
```

Set a static IPv6 address and gateway:

```
> config network ip static 2600:2104:5:3:2c88:2a32:5634:1234 2600:2104:5:3:2c88:1111  
Status='0,Success'
```

Set a static IPv6 address, netmask, and gateway:

```
> config network ip static 2600:2104:5:3:2c88:2a32:5634:1234 64 2600:2104:5:3:2c88:1111  
Status='0,Success'
```

Show the current network IP settings (dynamic IPv6 example):

```
> show network ip summary  
Status='0,Success'  
connectionStatus='Connected'  
ipAddressMode='Static'  
ipAddress='2600:2104:5:3:2c88:2a32:5634:1234'  
ipMask='64'  
gatewayAddress='2600:2104:5:3:2c88:1111'  
MACAddress='00:16:25:11:55:aa'
```

Config Network LLDP Command

Readers that support transmit power of 36 dBm ERP (Effective Radiated Power) as covered in the ETSI EN 302 208 draft specification, must be powered by a DC power supply or a Power-over-Ethernet switch that supports PoE+.

For these readers, the Link Layer Discovery Protocol (LLDP)/Cisco Discovery Protocol (CDP) is used to try to negotiate power with the PoE+-capable Ethernet switch, though not all PoE+ switches support software-based negotiation of LLDP/CDP.

LLDP/CDP is disabled by default on readers that require PoE+ power, but can be enabled with **config system power source auto** or disabled with **config system power source poe** or **config system power source poe+**.

Note: When the LLDP/CDP service is disabled and the Ethernet PoE+ switch cannot allocate sufficient electrical power, running an RO Spec on the reader may result in the reader rebooting.

Command	Argument	Format	Description
lldp	enable disable	enum	Enable and run or disable the LLDP service. When enabled, LLDP negotiates power with a PoE switch.

The **lldp** command might only be available in Reader models prior to the Impinj R700 RAIN RFID Reader.

Reader products that do not require PoE+ do not use LLDP/CDP and the rshell command is unsupported:

```
> config network lldp enable
Status='7,Unsupported-Command'
```

Config Network NTP Command

The **config network ntp** command allows the user to statically configure NTP servers. These servers are in addition to any provisioned through DHCP (up to six available DHCP servers may be automatically included as dynamic servers in the list of current NTP servers). You may add up to six statically configured NTP servers. The NTP service determines which of the available servers to synchronize with and will only synchronize to one server at a time.

The NTP service runs by default but may be disabled by entering the following RShell command:

```
> config network ntp disable
```

Inclusion of dynamically configured NTP services (provisioned via DHCP) is enabled by default but may be disabled using the following command:

```
> config network ntp dynamicservers disable
```

The command parameters are shown in the following table.

Table 4.15: Config Network NTP Command Parameters

Command	Argument	Format	Description
enable		<address>	Enable and start the NTP service.
disable		<address>	Disable and stop the NTP service.
add	<ntp server>	<address>	Add a static server (identified by either an IP address or hostname) to the list of current NTP servers. The NTP service must be disabled before adding a static server.

Command	Argument	Format	Description
del	<ntp server>	<address>	Delete a statically configured server (identified by either an IP address or hostname) from the list of current NTP servers. The NTP service must be disabled before deleting a static server.
delall			Delete all the statically configured NTP servers from the current list. The NTP service must be disabled before entering this command.
dynamicservers enable			Enable automatic inclusion of NTP servers provisioned via DHCP. The NTP service must be disabled before entering this command.
dynamicservers disable			Disable automatic inclusion of NTP servers provisioned via DHCP. The NTP service must be disabled before entering this command.

Note: Attempting to add an NTP server that has already been added will result in an error value of 3 (Invalid-Parameter-Value). Attempting to add more than six static NTP servers will result in an error value of 2 (Invalid-Command-Parameter). Attempting to change the system time (via “config system time”) while the NTP service is enabled will result in an error value of 8 (Permission-Denied). To manually change the system time you must first disable the NTP service (“config network ntp disable”). Attempting to change NTP settings (adding/deleting a static server or enabling/disabling dynamic servers) while the NTP service is enabled will result in a error value of 8 (Permission-Denied). Disable the NTP service before making any NTP settings changes and then re-enable the service.

An example of the command is:

```
> config network ntp add myntpserver.com
Status='0,Success'
```

Config Network Wlan Command

The **config network wlan** command allows the user to configure WiFi interface parameters. This command might only be available in Reader models prior to the Impinj R700 RAIN RFID Reader. Its configurable parameters are shown in the following table.

Table 4.16: Config Network Wlan Command Parameters

Command	Argument	Format	Description
nettype	infra adhoc	enum	Set the network type to infrastructure or adhoc.

Command	Argument	Format	Description
ssid	<ssid>	string	Set the WiFi SSID, up to 32 characters
keymgmt	wpa-psk wpa-none none	enum	Set the WiFi key management protocol.
encrypt	none wpa wpa2	enum	Set the encryption type for WPA/WPA2 secured connection.
psk	<preshared- key>	string	Set the preashred key used for WPA/WPA2 secured connection. Must be between 8 and 32 characters inclusive.
update	NA	NA	Save the parameters entered into persistent storage, and then apply them.
commit	NA	NA	Save the parameters entered into persistent storage without applying them.
quit	NA	NA	Discard the paramters entered.

The parameters entered are inter-dependent as shown in the following table for all supported use cases.

Table 4.17: WLAN Configuration Parameter Dependency

Use case	nettype	keymgmt	encrypt	psk	Description
Infrastructure, No security	infra	none	none	NA	No security, connect to other WiFi stations without any protection.
Infrastructure, WPA personal	infra	wpa- psk	wpa	<valid psk>	Connect to APs using WPA encryption and WPA encryption.
Infrastructure, WPA2 personal	infra	wpa- psk	wpa2	<valid psk>	Connect to APs using WPA2 encryption and WPA2 encryption.
Adhoc, No security	adhoc	none	none	NA	No security, connect to other WiFi stations without any protection.

Use case	nettype	keymgmt	encrypt	psk	Description
Adhoc, WPA	adhoc	wpa-none	wpa	<valid psk>	Connect to other WiFi stations using preshared key and WPA encryption.
Adhoc, WPA2	adhoc	wpa-none	wpa2	<valid psk>	Connect to other WiFi stations using preshared key and WPA2 encryption.

Inconsistent parameters will result in the following error:

```
Status='4,Parameter-Dependency-Error'
```

Here is an example of the command sequences for connecting to an infrastructure network with WPA2 security:

```
> config network wlan nettype infra
> config network wlan ssid "my network"
> config network wlan keymgmt wpa-psk
> config network wlan encrypt wpa2
> config network wlan psk <my-secret>
> config network wlan update
```

If you want to save the changes, but do not want to update your current connection, type:

```
> config network wlan commit
```

in which case the parameters are saved to flash memory and applied the next time the WiFi interface is activated.

Config Network HTTP Menu

The **config network http** menu allows the user to configure whether or not the http (web) server connection is enabled. There are only two configurable parameters, as shown in the following table. These settings will persist across reboots.

Table 4.18: Config Network HTTP Command Parameters

Command	Description
enable	Enables and starts the http server (default)
disable	Disables and stops the http server

An example of the command is:

```
> config network http enable
Status='0,Success'
```

Config Network HTTPS Menu

The **config network https** menu allows the user to configure whether or not the secure https (web) server connection is enabled. There are only two configurable parameters, as shown in the following table. These settings will persist across reboots.

Table 4.19: Config Network HTTPS Command Parameters

Command	Description
enable	Enables and starts the https server (default)
disable	Disables and stops the https server

An example of the command is:

```
> config network https enable
Status='0,Success'
```

Config Network FTP Command

The **config network ftp** command allows the user to configure whether or not the FTP server is enabled. There are only two configurable parameters as shown in the following table. These settings will persist across reboots.

Table 4.20: Config Network FTP Command Parameters

Command	Description
enable	Enables and starts the ftp server
disable	Disables and stops the ftp server (default)

An example of the command is:

```
> config network ftp enable  
Status='0,Success'
```

The ftp server is disabled by default. Disabling the ftp server will take effect immediately (a reboot is not required).

Note: Even when the ftp server is enabled, much of the file system is mounted read-only. As such, you may copy files from the reader but copying files to the reader will fail in most cases. For a full description of the default read/write state of file system partitions on the reader, please refer to the Impinj Reader and Gateway Embedded Developer's Guide.

Config Network SSH Command

The **config network ssh** command allows the user to configure whether or not the SSH server is enabled. There are only two configurable parameters as shown in the following table. These settings will persist across reboots.

Table 4.21: Config Network SSH Command Parameters

Command	Description
enable	Enables and starts the ssh server (default)
disable	Disables and stops the ssh server

An example of the command is:

```
> config network ssh enable  
Status='0,Success'
```

Config Network Port Security Command

The **config network portsecurity** command allows the user to configure whether or not 802.1x port-based authentication is enabled for the Ethernet port. There are also three configurable parameters as shown in the following table. These settings will persist across reboots.

Table 4.22: Config Network Port Security Command Parameters

Command	Description
dot1x enable	Enables and starts the dot1x service
dot1x disable	Disables and stops the dot1x service (default)

Command	Description
method MD5	Use MD5 authentication (default)
method PEAP	Use PEAP authentication
method MSCHAPv2	Use MSCHAPv2 authentication
access username <username>	Set the username used for authentication
access password <password>	Set the password used for authentication
reset	Resets to defaults

Notes: If the dot1x service is currently enabled, changes to the **method**, **username**, and/or **password** will not take effect until the device is rebooted or the service is manually disabled and reenabled.

The **username** and **password** are encrypted and stored locally on the device. The **username** and **password** are displayed as ‘...’ when requesting portsecurity configuration via the **show network portsecurity** command. The **username** and **password** are limited to 127 characters each.

Defaults: The default **method** is MD5. The default **username** is an empty string (“”). The default **password** is an empty string (“”).

An example of the command sequence is:

```
> config network portsecurity disable
Status='0,Success'
> config network portsecurity method PEAP
Status='0,Success'
> config network portsecurity access username user1
Status='0,Success'
> config network portsecurity access password pwd1
Status='0,Success'
> config network portsecurity dot1x enable
Status='0,Success'
```

Config Network SFTP Command

The **config network sftp** command allows the user to store the login credentials used to access an SFTP server. The commands are shown in the following table. This is presently used by the reader’s upgrade mechanism when an SFTP URI is used. The reader uses these login credentials to gain access to the SFTP server.

Table 4.23: Config Network Port Security Command Parameters

Command	Description
access username <username>	Set the username used to access the SFTP server
access password <password>	Set the password used to access the SFTP server
reset	Resets to defaults

Notes: The **username** and **password** are limited to 127 characters each. Once captured, they are encrypted and stored in the reader’s persistent partition.

If the **username** and/or **password** are properly specified as part of the URI, the reader will not use the stored credentials.

The **reset** sub-command will remove the stored credentials from the reader, as will a **config image default** command.

4.2.5 Config RFID Menu

The **config rfid** menu allows the user to set parameters of the Reader’s RFID control interface. The parameters are shown in the following table.

Table 4.24: Config RFID Command Parameters

Command	Description
resetstats	Reset the current RFID statistics.
llrp	Submenu of LLRP-specific configuration commands.
interface	Submenu of RFID interface configuration.

Config RFID ResetStats Command

The **config rfid resetstats** command resets the RFID statistics maintained by the Reader.

An example of the command and response is shown below:

```
> config rfid resetstats
Status='0,Success'
```

Config RFID LLRP Command

The **config rfid llrp** command allows the user to configure the LLRP implementation. The parameters are shown in the following table.

Table 4.25: Config RFID LLRP Commands

Command	Description
connclose	Initiate a manual close of the current LLRP connection. If no connection exists, a status code of '8-Permission-Denied' will be returned.
factory	Resets the LLRP configuration to its factory defaults. Deletes all configured RO Specs and Access Specs and restores the factory default LLRP configuration. This action resets only in-band configuration, not configuration items controlled by RShell. Note that this command will be rejected with a status code of '8-Permission-Denied' if a LLRP client connection exists
resetstats	Reset the current LLRP specific statistics maintained by the Reader.

Config RFID LLRP Inbound Commands

The **config rfid llrp inbound** command provides a submenu of client-initiated connection configuration commands. Currently only the **tcp** subcommand is supported, which has its own series of subcommands, as described in the following table.

Table 4.26: Config RFID LLRP Inbound TCP Command Parameters

Command	Argument	Format	Description
port	<port number>	integer	Configure the port on which TCP connections are accepted. Default is IANA-assigned port of 5084 for the standard LLRP connections (security set to none) and port 5085 for secure LLRP connections (security set to encrypt).
service	on off	enum	Turn on or off LLRP client-initiated TCP connections to the Reader. Disabling this service will cause all future connection attempts to be refused. Enabling this service will cause the Reader to accept new connections at the port configured using the port subcommand. Current LLRP connections are not affected by this command.
security	none encrypt	enum	Selecting none will disable validation and encryption. Selecting encrypt will encrypt but not validate data over the LLRP connection.

Note: Usage of port 5085 is not allowed for standard LLRP connections (security set to **none**) and usage of port 5084 is not allowed for usage of secure LLRP connections (security set to **encrypt**).

Usage: **config rfid llrp inbound tcp port <port number>**

Usage: `config rfid llrp inbound tcp service <on|off>`

Usage: `config rfid llrp inbound tcp security <none|encrypt>`

Config RFID LLRP Outbound Commands

The `config rfid llrp outbound` command leads to a submenu of Reader-initiated connection configuration commands, as shown in the following table.

Table 4.27: Config RFID LLRP Outbound Command Parameters

Command	Argument	Format	Description
add	<hostname> [:port]	string [:integer]	Add a new host to which the Reader will attempt Reader-initiated LLRP connections. This host is mandatory, but the port number is optional. If the port number is omitted, the Reader will attempt to connect to the remote host at the default IANA LLRP port of 5084. A maximum of 5 servers can be added. The Reader will attempt to establish a connection to each of the servers in a round-robin manner. After a connection is established, the procedure will stop. If the connection is lost, the procedure will restart with the first configured server.

Command	Argument	Format	Description
del	<hostname> [:port]	string [:integer]	Delete a specific remote host to which the Reader attempts Reader-initiated LLRP connections. The host and port combination must be preconfigured for the command to succeed.
delall			Delete all remote hosts to which Reader attempts Reader-initiated LLRP connections.
open	<hostname> [:port]	string [:integer]	Attempt to open an LLRP connection to the specified remote host. and the host and port combination is not preserved. This command can only be used as a debugging aid. For normal scenarios using Reader-initiated connections, use the “add” command parameter. This command will always return the status ‘10,Command-Being-Processed’. The disposition of the connection after the command is immediately available. To determine if the connection was successful, use the summary command.
retry	<retry timeout>	integer	Configure the period in seconds between Reader-initiated connection attempts. The number represents the minimum number of seconds between failed connection attempt and the next attempt by the Reader. The Reader uses a geometric progression back-off timer. If the retry timeout argument is not specified, the Reader will attempt to connect to the remote host every 5 seconds, 10 seconds, 20 seconds, 40 seconds, etc. After a successful connection is established, the timer is reset to the minimum value and the next connection attempt will fail if the connection fails.

Command	Argument	Format	Description
service	on off	enum	Turn on/off LLRP Reader-initiated connections. Disabling this service prevents future connection attempts to be made. Enabling this service will cause the reader to make connection attempts to any connected readers. Current LLRP connections are not affected by this command.
timeout	<timeout>	integer	Configure the timeout (in seconds) for Reader-initiated connections before the reader retries. If the TCP handshake has not completed within this timeout period, the next connection attempt is subject to the geometric back-off algorithm. On a high-latency WAN, one could tune this timeout higher so that the Reader waits longer for the handshake to complete before doing another connection attempt. A failed handshake will invoke the retry timer. For more information, see the retry command entry.
security	none encrypt encryptvalidate	enum	Set security options for reader-initiated connections (TLS 1.2). You can disable the security for reader-initiated connections (none), enable encryption (encrypt), or enable encryption and peer validation (encryptvalidate).

Note: The **security encryptvalidate** option supports only preinstalled certificates from well-known CAs.

Config RFID Interface Command

The **config rfid interface** command sets the RFID interface of the reader to either LLRP or REST. This command is only available on the R700 reader.

The **config rfid interface** command parameters are shown in the following table.

Table 4.28: Config RFID Interface Command Parameters

Command	Description
llrp	Enable Impinj LLRP Interface.
rest	Enable Impinj RESTful Interface.

You can configure the reader interface through the reader webpage as well. Select either **Impinj LLRP Interface** or **Impinj RESTful Interface** from the **Available Interfaces** menu in the **READER INTERFACE** section of the page and then click the **Update** button (figure 4.2). The page will update the setting information in the **Reader Interface** section on the left side.



Figure 4.2 Reader interface menu

4.2.6 Config SNMP Command

The **config snmp** menu allows the user to configure the SNMP settings for the Reader. The **config snmp** command parameters are shown in the following table.

Table 4.29: Config SNMP Command Parameters

Command	Description
service	Enable/Disable the SNMP service.
trapservice	Enable/Disable SNMP trap service.
reset	Reset SNMP settings to default values.
access	Submenu of access specific commands.
write	Submenu of write specific commands.
epcg	Submenu of EPCglobal RM MIB specific commands.
trap	Submenu of trap specific commands.
version	Submenu of version specific commands.
v3	Submenu of SNMP V3 specific commands.

Config SNMP Service Command

The following table shows the **config snmp service** parameters.

Table 4.30: Config SNMP Service Command Parameters

Command	Argument	Format	Description
service	enable disable	enum	Globally enable/disable the SNMP service. When the service is enabled, it is started, and when it is disabled, it is stopped. If the service is enabled when the system boots, the SNMP service will be started.

Example to enable the service:

```
> config snmp service enable
Status='0,Success'
```

Config SNMP TrapService Command

The following table shows the **config snmp trapservice** parameters.

Table 4.31: Config SNMP TrapService Command Parameters

Command	Argument	Format	Description
trapservice	enable disable	enum	Globally enable/disable the SNMP trap service. When the service is enabled, it is started, and when it is disabled, it is stopped. If the service is enabled when the system boots, the SNMP service will be started.

When the trapservice is enabled, the following standard traps are sent:

> **coldStart (.1.3.6.1.6.3.1.1.5.1)**

This trap is sent when the SNMP service is restarted. The SNMP service is restarted when SNMP parameters are changed.

> **nsNotifyShutdown (.1.3.6.1.4.1.8072.4.0.2)**

This trap is sent when a normal shutdown is requested (e.g. an rshell reboot request).

> **nsNotifyRestart (.1.3.6.1.4.1.8072.4.0.3)**

This trap is sent when the SNMP service is reconfigured. The SNMP service is reconfigured when certain systems settings are changed (e.g. when the hostname changes).

> **authenticationFailure (.1.3.6.1.6.3.1.1.5.5)**

This trap is an unknown community name is used in a V2c request or an unknown passphrase is used in a V3 request.

When the trapservice is enabled, the following custom (Impinj-defined) traps may be explicitly enabled:

> **impUnexpectedRestart (.1.3.6.1.4.1.25882.4.1)**

This trap is sent when the reader experiences an unexpected shutdown.

Note: The exact circumstances under which these traps may be sent is subject to change in future releases of the Octane and R700 firmware.

Example to enable the trap service:

```
> config snmp trap service enable
Status='0,Success'
```

Config SNMP Reset Command

This command resets the SNMP settings to the default values. There are no parameters required for this command.

Example to reset SNMP settings to default values:

```
> config snmp reset
Status='0,Success'
```

Config SNMP Access Command

The **config snmp access** command allows the user to configure the SNMP read and write access settings for the Reader. The **config snmp access** command parameters are shown in the following table.

Table 4.32: Config SNMP Access Command Parameters

Command	Argument	Format	Description
rocommunity	<read-only string>	string	Sets the read-only community string for read access to SNMP attributes.
rwcommunity	<read-write string>	string	Sets the read-write community string for read-write access to SNMP attributes. If SNMP writes are disabled this string may still be used to read via SNMP.
trapcommunity	<trap string>	string	Sets the trap community string for allowing receipt of SNMP notifications from the reader.

Note: The rocommunity and rwcommunity may not be set to the same string. Attempting to set both rocommunity and rwcommunity to the same string will result in the error: Status='3,Invalid-Parameter-Value'.

Example to set the rocommunity string to “my-read-only-password”:

```
> config snmp access rocommunity my-read-only-password
Status='0,Success'
```

Config SNMP Write Command

The **config snmp write** command allows the user to configure whether SNMP writes are allowed (enabled) or not (disabled). If writes are disabled, then SNMP writes are allowed (for any agents), even if the rwcommunity is set properly. If the SNMP service is enabled, writes are enabled, and the rwcommunity is set properly, then writable SNMP values can be modified. Note that no reader specific settings are currently writable via SNMP. Refer to the Octane SNMP document for more information. The **config snmp write** command parameters are shown in the following table.

Table 4.33: Config SNMP Write Command Parameters

Command	Argument	Format	Description
enable	all	string	Enable SNMP writes on all writeable objects.
disable	all	string	Disable SNMP writes on all writeable objects.

Example to enable SNMP writes:

```
> config snmp write enable all
Status='0,Success'
```

Config SNMP EPCG Command

The **config snmp epcg** menu provides control of the EPCglobal RM MIB. There are no direct subcommands and only one submenu, device, for this command.

Config SNMP EPCG Device Command

The **config snmp epcg device** command is used to configure epcg device settings. Currently, the device **role** is the only settings that can be configured. The **config snmp epcg device** command parameters are shown in the following table.

Table 4.34 Config SNMP EPCG Device Command Parameters

Command	Argument	Format	Description
role	<role>	string	The string that should be reported for device role.

Example to configure the epcg device role to “my-reader-role”:

```
> config snmp epcg device role my-reader-role
Status='0,Success'
```

Config SNMP Trap Command

The **config snmp trap** command allows the user to configure whether sending SNMP traps from the reader are allowed (enabled) or not (disabled). The **config snmp trap** command parameters are shown in the following table.

Table 4.35: Config SNMP Trap Command Parameters

Command	Argument	Format	Description
enable	<trap>	string	Enable sending standard traps and the specified custom SNMP trap. Supported custom traps: unexpectedrestart
disable	<trap>	string	Disable sending standard traps and the specified custom SNMP trap. Supported custom traps: unexpectedrestart
sink	<host>	string	Hostname or IP address to receive SNMP notifications.
sink2	<host>	string	Additional hostname or IP address to receive SNMP notifications.
sink3	<host>	string	Additional hostname or IP address to receive SNMP notifications.
sink4	<host>	string	Additional hostname or IP address to receive SNMP notifications.
delall			Clear all SNMP trap (notification) sinks.
port	<port>	string	UDP port to send SNMP traps to (default is 162).

Note: The trap port setting applies to all SNMP trap sinks.

Note: The unexpected restart trap (.1.3.6.1.4.1.25882.4.1) is sent when the reader restarts due to an unexpected software or hardware error. Refer to the IMPINJ-ROOT-REG-MIB.mib file for more details.

Example to enable the unexpected restart trap:

```
> config snmp trap enable unexpectedrestart
Status='0,Success'
```

Config SNMP Version Command

The **config snmp version** command allows the user to configure whether SNMP version 2c and version 3 security models are enabled or disabled. Each model can be enabled or disabled separately. When version 2c is enabled, version 1 requests are also allowed (with the appropriate community string). The **config snmp version** command parameters are shown in the following table.

Table 4.36: Config SNMP Version Command Parameters

Command	Argument	Format	Description
2c	enable disable	enum	Enable the SNMP version 1 and 2c security model. When enabled, SNMP client applications can communicate with the reader using using the v1 or v2c protocol.
3	enable disable	enum	Enable the SNMP version 3 security model. When enabled, SNMP client applications can communicate with the reader using the v3 protocol.

Note: Refer to the Octane SNMP documentation and the IMPINJ-ROOT-REG-MIB.mib file for more details on Octane SNMP support.

Example to enable version 2c security model support:

```
> config snmp version 2c enable
Status='0,Success'
```

Config SNMP V3 Command

The **config snmp v3** command allows the user to configure V3 security model specific parameters. Octane currently supports only one read-only user and no read-write users. The **config snmp v3** command parameters are shown in the following table.

Table 4.37: Config SNMP V3 Command Parameters

Command	Argument	Format	Description
ro auth rouser	<username>	string	Specify the read-only username.
ro securitylevel	<noauth auth>	enum	Specify authentication and/or encryption of read-only user requests.
ro auth passphrase	<passphrase>	string	Specify read-only authentication passphrase.

Command	Argument	Format	Description
ro auth method	<MD5>	enum	Specify read-only authentication method.

Note: Refer to the Octane SNMP documentation and the IMPINJ-ROOT-REG-MIB.mib file for more details on Octane SNMP support.

Example to set the authentication method for the read-only user:

```
> config snmp v3 ro auth method MD5
Status='0,Success'
```

Config Version Compatibility

Support for version 2c and version 3 get requests can be enabled or disabled independently.

Only version 2c traps are supported.

Version 2c traps are sent if both the SNMP service and trapservice are enabled (and appropriate sink, port and trapcommunity values are set).

Version 2c read (get, getnext, and walk) requests are supported if the SNMP service is enabled and version 2c is enabled (and the appropriate rocommunity is set).

Version 3 read (get, getnext, walk) requests are supported if the SNMP service is enabled and version 3 is enabled (and the appropriate v3 values are set).

4.2.7 Config System Menu

This menu allows configuration of the system operating region, time and identification parameters. See the following table for a description of the configuration system command parameters.

Warning: By changing the Reader’s operating region, you are changing the Reader’s RF settings. The RF settings must match the country or region of operation to comply with local laws and regulations. You, the user, are responsible to ensure operation with the correct RF settings and are solely responsible for any fines and other damages due to incorrect or non-compliant country/region settings on your Reader.

Table 4.38: Config System Command Parameters

Command	Argument	Format	Description
contact	<contact string>	string	Configure the system contact. ASCII characters are allowed, except for single and double quotes. Double and single quotes can only be used if the leading and trailing characters of the string has white space.
description	<description string>	string	Configure the system description. ASCII characters are allowed, except for single and double quotes. Double and single quotes can only be used if the leading and trailing characters of the string has white space.
location	<location string>	string	ASCII characters are allowed, except for single and double quotes. Double and single quotes can only be used if the leading and trailing characters of the string has white space.
name	<name string>	string	ASCII characters are allowed, except for single and double quotes. Double and single quotes can only be used if the leading and trailing characters of the string has white space.
region	<region number>	Integer	Certain Reader models permit the user to select an alternate operating region. Each operating region is encoded as an integer. Alternate regions (if available) can be found by issuing a show system region command.

Command	Argument	Format	Description
time	<time value>	MMDDhhmmCCYY MM.DD-hh:mm:ss CCYY.MM.DD- hh:mm:ss CCYY.MM.DD- hh:mm hh:mm:ss hh:mm	Configure the system time. Time must be entered in one of the approved formats. If the year is set explicitly when setting the time, the year must be at least 2000. Also, the date may not be greater than January 2038. See Note below.
power			Submenu of power specific configuration commands.

Note: To use this command to set the system time, you must disable the NTP service (“config network ntp disable”). Failure to do so will result in a “Permission-Denied” error.

A sample command that sets the system location to “my-reader-location” is shown below:

```
> config system location my-reader-location
Status='0,Success'
```

A sample command that sets the system time is shown below: (Time is set to April, 27th 1:11:00 p.m. 2012.)

```
> config system time 042713112012
Status='0,Success'
```

Config System Power Command

Readers that support transmit power of 36 dBm ERP (Effective Radiated Power) as covered in the ETSI EN 302 208 draft specification, must be powered by a DC power supply or a Power-over-Ethernet switch that supports PoE+.

For these readers, the Link Layer Discovery Protocol (LLDP)/Cisco Discovery Protocol (CDP) is used to try to negotiate power with the PoE+-capable Ethernet switch, though not all PoE+ switches support software-based negotiation of LLDP/CDP.

LLDP/CDP is enabled by default on readers that require PoE+ power, but can be disabled with **config system power source auto**, or reenabled with **config system power source poe** or **config system power source poe+**.

The **config system power** command might only be available in the Impinj R700 RAIN RFID Reader and later models.

Note: When the LLDP/CDP service is disabled and the Ethernet PoE+ switch cannot allocate sufficient electrical power, running an RO Spec on the reader may result in the reader rebooting or browning out.

Command	Argument	Format	Description
source	PoE PoE+ Auto	enum	The power source (PoE or Power over Ethernet, PoE plus, or automatic negotiation).
timeout	<milliseconds>	integer	The maximum time to negotiate the power source with a PoE switch. Only used if source is set to auto . Can delay startup if the PoE switch is slow to send LLDP power information.

Reader products that do not require PoE+ do not use LLDP/CDP and the rshell commands are unsupported:

```
> config system power source poe+
Status='7,Unsupported-Command'
> config system power timeout 20000
Status='7,Unsupported-Command'
```

Config System Region Command

When you change the Reader's operating region, the change does not take effect until the next reboot. If you attempt RFID operations on the Reader after you change the region but before you reboot the Reader, you will get unexpected behavior.

4.2.8 Config Feature Menu

The **config feature** menu allows the user to activate, enable and disable features in the Reader. The command parameters are shown in the following table.

Table 4.39: Config Features Command Parameters

Command	Description
activate	Activates a specified feature.
enable	Enables an active feature.
disable	Disables an active feature.

Config Feature Activate Command

The following table shows the **config feature activate** parameters.

Table 4.40: Config Feature Activate Command Parameters

Argument	Format	Description
<feature name>	enum	Activates the specified <feature name>, with a valid <key>.
<key>	integer	
[<type>]	enum	Optionally, a feature might need an additional <type> parameter.

Config Feature Enable and Disable Commands

The **config feature enable** command allows the user to enable a feature. The **config feature disable** command allows the user to disable a feature. The parameter for each command is shown in the following tables.

Table 4.41: Config Feature Enable and Disable Command Parameters

Command	Argument	Format	Description
enable	<feature name>	enum	Enable <feature name>. See the following table for the list of supported features.
disable	<feature name>	enum	Disable <feature name>. See the following table for the list of supported features.

Table 4.42: Supported Enable/Disable Features

Feature	Description
anthub	The Impinj Antenna Hub (available on R120 and R420)

For example, to enable the Antenna Hub feature:

> **config feature enable anthub**

Status='0,Success'

And to disable the Antenna Hub feature:

> **config feature disable anthub**

Status='0,Success'

4.3 Show Command

The **show** command has several submenus, as shown in the following table, and described in the following sections.

Table 4.43: Show Command Parameters

Command	Description
image	Submenu of image status commands.
logging	Submenu of logging status commands.
network	Submenu of network status commands.
rfid	Submenu of RFID status commands.
snmp	Submenu of SNMP status commands.
system	Submenu of system status commands.
feature	Submenu of feature status commands.
anthub	Submenu of anthub status commands.

4.3.1 Show Image Menu

The **show image** menu contains commands that are shown in the following table.

Table 4.44: Show Image Command Parameters

Command	Description
metafile	Displays information about the current upgrade metafile. If no metafile has ever been successfully downloaded, only a subset of the available fields are shown. See the following table for command responses.
summary	Displays the Reader's image information. See the following table.
version	Displays all version information for a partition on the current image.

The upgrade command, **UpgradeStatus** can take any of the arguments values shown in the following table. For each abnormal status, a reason parameter is given to indicate the reason for the status. The reason values are also given in the following table.

Table 4.45: Show Image Metafile Response Parameters

Argument	Format	Description
MetafileUri	string	The current upgrade metafile URI.
RetrieveMode	Manual Auto	The current retrieve mode.
RetrievePeriod	integer	The current retrieve period, present only mode is auto . This period is specified in
UpgradeMode	auto forced	The upgrade mode in use if the metafile is currently available
CommitMode	immediate scheduled wait-4-cmd	The commit mode if metafile is currently available
CommitTime	string	The scheduled commit time, which is present only if the commit mode is set to scheduled . The format is <code><timezone-yyyy-mm-dd-hh-mm-ss></code> . Current time is in GMT is supported.
EarlyActOk	yes no	Indicates whether an early activation of the upgrade image is allowed if the commit mode is scheduled . Present only if the metafile has the early-act-ok field.
DownloadRetries	integer	Number of times to retry a failed download
DownloadRetryPeriod	integer	Number of seconds between retry attempts
ReaderModelName	string	The model name of the Reader. This indicates the model section of the metafile was used to
ImageType	integer	Firmware image upgrade file type (present only if the metafile has the image-type field)
DownloadMode	immediate fixed-delay <delay> random-delay <delay>	Indicates the current download mode. For fixed or random delay, the DownloadDelay field indicates the corresponding the delay value.
DownloadDelay	integer	For fixed delay, this is a constant offset. For random delay, this is the maximum value for a random offset.
ImageFileUri	uri	URI from which the file image is retrieved

Examples of possible **show image summary** command responses are shown in the following two tables, along with the corresponding field formats. A code example follows these two tables.

Table 4.46: Show Image Summary Response Parameters

Argument	Format	Description
UpgradeStatus		The upgrade status of the last executed upgrade. The following enumerations are possible values for the UpgradeStatus field.
	Ready	Application is ready for additional commands.
	WaitingForMetafileTransfer	Metafile is being transferred from server.
	WaitingForMetafileRetry	Metafile transfer timed out, waiting for subsequent transfer.
	ProcessingMetafile	Metafile was received and is being validated.
	DeterminingNeedForImageFile	Version information is being examined to determine if the image file needs to be retrieved.
	WaitingForImageFileTransfer	Image file is being transferred from server.
	WaitingForImageFileRetry	Image file transfer timed out, waiting for subsequent transfer.
	ProcessingImageFile	Image file is being validated.
	WaitingForCommitImage	Image file is being committed to flash memory.
	SchedulingActivation	Image activation is being scheduled.
	WaitingToActivateImmediate	Image is being activated, and will be followed by immediate reboot.
	WaitingToActivateScheduled	Image is being activated, and reboot is scheduled based on user specified commit time.
	WaitingRandomRebootDelay	System is in the random delay window (provided as part of commit time specification) prior to system reboot.
	WaitingForFallback	A config image fallback command is being processed and preparing to reboot the system.
	WaitingForCDR	A config image default command is being processed and preparing to reboot the system.
	WaitingForRequestedReboot	Reader is about to be rebooted.

Argument	Format	Description
LastOperation		This supplements the UpgradeStatus field to give a reason for the status. This is only displayed or provided in conjunction with the next line (LastOperationStatus). Typically status reasons are provided only when additional information is required, such as under error scenarios or when a system reboot has been scheduled. This generally reports the condition leading up to the current status.
	Unknown Host	Download failed because of an unknown host.
	Unsupported Scheme	Download failed because of unsupported URI scheme (only FTP, HTTP, TFTP and SFTP are supported).
	Syntax Error	Metafile has a syntax error.
	Timeout	Download timed out.
	File Not Found	Download file not found.
	Access Denied	Download failed because of access denied by server, such as for a bad password.
LastOperationStatus	Not Matching Metafile	Upgrade image did not match the version specified in the metafile.
	Bad File Format	Bad upgrade image file format.
	Bad CRC	Bad image CRC.
	No Matching Hardware Version	Image file does not contain a hardware version that matches the Reader hardware version.
	No Newer Version	Upgrade not needed because no newer version in the metafile or upgrade image.
	File Mismatch	Metafile has mismatched partition image types.
	No File	Metafile does not contain upgrade file information.
	Missing SOP	Metafile does not contain SOP partition while an SPP is present.
	Duplicated Partition	Upgrade failed because either the metafile or the upgrade file has a duplicated partition in it.

Argument	Format	Description
	Incompatible Upgrade/Downgrade Path	Upgrade failed because upgrading/downgrading to the intended SOP version or type is not allowed by current image.
	Flash Programming Failed Current Image Invalidated	Failed to write the flash memory. The current image has been invalidated by a previous “fallback” command.
	No Fallback Image Available	This reason applies to the rejection of multiple commands following a “fallback” command.
	Generic Error	Download error other than those specified above.

Argument	Format	Description
UpgradeStatus		The upgrade status of the last executed upgrade. The following enumerations are possible values for the UpgradeStatus field.
	Ready	Application is ready for additional commands.
	WaitingForMetafileTransfer	Metafile is being transferred from server.
	WaitingForMetafileRetry	Metafile transfer timed out, waiting for subsequent transfer.
	ProcessingMetafile	Metafile was received and is being validated.
	DeterminingNeedForImageFileVersion	Information is being examined to determine if the image file needs to be retrieved.
	WaitingForImageFileTransfer	Image file is being transferred from server.
	WaitingForImageFileRetry	Image file transfer timed out, waiting for subsequent transfer.
	ProcessingImageFile	Image file is being validated.
	WaitingForCommitImage	Image file is being committed to flash memory.
	SchedulingActivation	Image activation is being scheduled.
	WaitingToActivateImmediate	Image is being activated, and will be followed by immediate reboot.

Argument	Format	Description
LastOperation	WaitingToActivateScheduled	Image is being activated, and reboot is scheduled based on user specified commit time.
	WaitingRandomRebootDelay	System is in the random delay window (provided as part of commit time specification) prior to system reboot.
	WaitingForFallback	A config image fallback command is being processed and preparing to reboot the system.
	WaitingForCDR	A config image default command is being processed and preparing to reboot the system.
	WaitingForRequestedReboot	Reader is about to be rebooted.
		This supplements the UpgradeStatus field to give a reason for the status. This is only displayed or provided in conjunction with next line (LastOperationStatus). Typically status reasons are provided only when additional information is required, such as under error scenarios or when a system reboot has been scheduled. This generally reports the condition leading up to the current status.
	Unknown Host	Download failed because of an unknown host.
	Unsupported Scheme	Download failed because of unsupported URI scheme (only FTP, HTTP, TFTP and SFTP are supported).
	Syntax Error	Metafile has a syntax error.
	Timeout	Download timed out.
LastOperationStatus	File Not Found	Download file not found.
	Access Denied	Download failed because of access denied by server, e.g., bad password.
	Not Matching Metafile	Upgrade image did not match the version specified in the metafile.
	Bad File Format	Bad upgrade image file format.
	Bad CRC	Bad image CRC.

Argument	Format	Description
	No Matching Hardware Version	Image file does not contain a hardware version matching the Reader hardware version.
	No Newer Version	Upgrade not needed because no newer version in the metafile or upgrade image.
	File Mismatch	Metafile has mismatched partition image types.
	No File	Metafile does not contain upgrade file information.
	Missing SOP	Metafile does not contain SOP partition while an SPP is present.
	Duplicated Partition	Upgrade failed because either the metafile or the upgrade file has a duplicated partition in it.
	Incompatible Upgrade/Downgrade Path	Upgrade failed because upgrading/downgrading to the intended SOP version or type is not allowed by current image.
	Flash Programming Failed	Failed to write the flash memory.
	Current Image Invalidated	The current image has been invalidated by a previous “fallback” command.
	No Fallback Image Available	This reason applies to the rejection of multiple commands following a “fallback” command.
	Generic Error	Download error other than those specified above.

Table 4.47: Show Image Summary Response Parameters (continued)

Argument	Format	Description
PrimaryImageType	integer	The image type number for the primary image (10).
PrimaryImageState	enum	The current state of the primary image (this should always be Active). Refer to the Show Image Summary Response Parameters Table for details of image state values.
PrimaryImageSystem-Version	string	The version of the primary image’s system OS partition.
PrimaryImageConfig-Version	string	The current version of the primary image’s persistent partition. ‘255.255.255.255’ is the default SPP version.

Argument	Format	Description
PrimaryImage-CustomApp-Version	string	The version of the primary image's custom application partition. This displays only if CAP is present.
SecondaryImageType	integer	The image type number for the secondary image (10). If the secondary image is not valid this argument is not shown.
SecondaryImageState	enum	The current state of the secondary image would typically have one of the values from the Show Image Summary Response Parameters table. If the secondary image is not valid this argument is not shown.
SecondaryImageSystem-Version	string	The version of the secondary image's system OS partition. If the secondary image is not valid this argument is not shown.
SecondaryImageConfig-Version	string	The current version of the secondary image's persistent partition. '255.255.255.255' is the default SPP version. If the secondary image is not valid this argument is not shown.
SecondaryImageCustomAppVersion	string	The version of the primary image's custom application partition. This displays only if CAP is present. If the secondary image is not valid this argument is not shown.

An example:

```
> show image summary
Status='0,Success'
UpgradeStatus='Ready'
PrimaryImageType='10'
PrimaryImageState='Active'
PrimaryImageSystemVersion='5.2.0.240'
PrimaryImageConfigVersion='255.255.255.255'
PrimaryImageCustomAppVersion='1.0.0.0'
SecondaryImageType='10'
SecondaryImageState='Active'
SecondaryImageSystemVersion='4.12.0.240'
SecondaryImageConfigVersion='255.255.255.255'
```

SecondaryImageCustomAppVersion='1.0.0.0'

Image State

An image state has four possible values, active, pre-active, pending, and obsolete, which are described in the following table.

Table 4.48: Image State Values

State Value	Meaning
Active	Image has been previously run and is eligible to fallback to.
Pre-Active	Image has been activated and is ready to become the Primary image on next reboot.
Pending	Image has been committed to flash memory, waiting for commit time to move it to the Pre-Active state.
Obsolete	Image has been invalidated, typically due to a fallback operation

4.3.2 Show Logging Menu

The **show logging** menu displays the logging configuration for the system and for displaying the actual logged information in text form. The commands are described in the following table. Log entries are shown in chronological order, with the most recent entry displayed last.

Response parameters for the **show logging** events and the **show logging summary** command (which displays the summary of response parameters along with security levels) are shown in the following tables.

Table 4.49: Show Logging Command Parameters

Command	Arguments	Format	Description
events	(err app) <event count>	enum, integer	Uses the event count number to determine how many of the last internal log entries to display.
summary			Displays the current user logging configuration. The “Show Logging Summary Response Parameters” table displays the summary of response parameters along with severity levels.

Table 4.50: Show Logging Events Response Parameters

Argument	Format	Description
Event1	string	The string responses from the log events.
Event2	string	
...
Event<n>	string	

The following table displays the summary of response parameters along with severity levels.

Table 4.51: Show Logging Summary Response Parameters

Argument	Format	Description
Managementlevel	Emergency Alert Critical Error Warning Notice Info Debug	Log severity level for Management
RFIDLevel		Log severity level for RFID
SystemLevel		Log severity level for System

Samples of the commands are shown below:

```

> show logging summary
Status='0,Success'
ManagementLevel='Error'
SystemLevel='Error'
RFIDLevel='Error'
> show logging events app 3
Status='0,Success'
Event1='Dec 4 00:22:46 (none) sshd[20090]: lastlog_openseek: Couldn't stat
/var/log/lastlog: No such file or directory'
Event2='Dec 4 00:22:53 (none) Rshell: User entered "show logging summary" '
Event3='Dec 4 00:22:53 (none) Rshell: ICTL target syslogconf returned status 0 '

```

4.3.3 Show Network Menu

The **show network** menu contains commands to display networking parameters and statistics. All commands are single word commands and take no arguments. Commands are shown in the

following table, while the response parameters are shown in the tables that follow this table.

Table 4.52: Show Network Menu Commands

Command	Description
dns	Summary of DNS settings
icmp	ICMP statistics
dnssd	Summary of DNSSD settings
mdns	Display current status of mDNS
ntp	Summary of NTP settings
summary	Summary of network settings
tcp	TCP statistics
udp	UDP statistics
http	Http server status
https	Https server status
ftp	FTP server status
ssh	SSH server status
portsecurity	Port Security Settings
sftp	SFTP settings
lldp	Display LLDP status
wlan (sub-menu)	WiFi adapter configuration submenu
ip (sub-menu)	IP statistics submenu

The **lldp** and **wlan** commands might only be available in Reader models prior to the Impinj R700 RAIN RFID Reader.

Table 4.53: Show Network DNS Response Parameters

Argument	Format	Description
Domain<n>Static	string	Statically configured domain (if configured)
Domain<n>Dynamic	string	DNS domain obtained from DHCP (if available)
Server<n>Static	ip address	Address of the Nth static DNS server
Server<n>Dynamic	ip address	Address of the Nth dynamic DNS server

Table 4.54: Show Network ICMP Response Parameters

Argument	Format	Description
icmpInMsgs	integer	See MIB-2 RFC 1213
icmpInErrors	integer	
icmpInDestUnreachs	integer	

Argument	Format	Description
icmpInTimeExcds	integer	
icmpInParmProbs	integer	
icmpInSrcQuenchs	integer	
icmpInRedirects	integer	
icmpInEchos	integer	
icmpInEchoReps	integer	
icmpInTimestamps	integer	
icmpInTimestampReps	integer	
icmpInAddrMasks	integer	
icmpInAddrMaskReps	integer	
icmpOutMsgs	integer	
icmpOutErrors	integer	
icmpOutDestUnreachs	integer	
icmpOutTimeExcds	integer	
icmpOutParmProbs	integer	
icmpOutSrcQuenchs	integer	
icmpOutRedirects	integer	
icmpOutEchos	integer	
icmpOutEchoReps	integer	
icmpOutTimestamps	integer	
icmpOutTimestampReps	integer	
icmpOutAddrMasks	integer	
icmpOutAddrMaskReps	integer	

Table 4.55: Show Network mDNS Response Parameters

Argument	Format	Description
mDNSStatus	enabled disabled NotAvailableOnCurrentInterface	Indicates the current state of the mDNS service. When the active interface is cellular and the status is enabled , it shows as NotAvailableOnCurrentInterface.

Table 4.56: Show Network HTTP Response Parameters

Argument	Format	Description
ServiceEnabled	True False	Indicates whether or not the service will be started at boot time.

Table 4.57: Show Network HTTPS Response Parameters

Argument	Format	Description
ServiceEnabled	True False	Indicates whether or not the service will be started at boot time.

Table 4.58: Show Network SSH Response Parameters

Argument	Format	Description
ServiceEnabled	True False	Indicates whether or not the service will be started at boot time.

Table 4.59: Show Network FTP Response Parameters

Argument	Format	Description
ServiceEnabled	True False	Indicates whether or not the service will be started at boot time.

Table 4.60: Show Network NTP Response Parameters

Argument	Format	Description
ServiceEnabled	True False	Indicates whether or not the NTP service will be started at boot time.
DynamicServersEnabled	True False	Indicates whether or not NTP servers discovered via DHCP will be included in the list of NTP servers.
Synchronized	True False	Indicates whether or not the NTP service has successfully synchronized with an NTP server.

Argument	Format	Description
SynchronizedServer	string IP Address	If the NTP service has successfully synchronized with an NTP server, that server IP address or hostname is specified here.
NtpServerDynamic<n>-Address NtpServerStatic<n>-Address	string IP Address	Hostname or IP address of the Nth static or dynamic NTP server
NtpServerDynamic<n>-State NtpServerStatic<n>-State	Synchronized Polled SymmetricActive SymmetricPassive ReceivingBroadcast SendingBroadcast	The current state of the first dynamic NTP server. When the Reader is trying to use a server, it will remain in the state Polled until it has successfully communicated with the server eight times. During this process, the <i>NtpServerDynamic/Static<n>Reach</i> parameter will generally transition through 3, 7, 17, 37, 77, 177, and 377. When the Reader has selected a server and locked on to it, the state parameter will become Synchronized .
NtpServerDynamic<n>-Stratum NtpServerStatic<n>-Stratum	integer	The current stratum number of the NTP server.
NtpServerDynamic<n>- Reach NtpServerStatic<n>- Reach	integer	The reachability register of the NTP server.

Note: If a pooled NTP server, such as pool.ntp.org, is specified as a dynamic or static NTP server, rshell may not be able to correctly display the NTP server status in the NtpServerDyanamic<n>-Xxx or NtpServerStatic<n>-Xxx response parameters. The Synchronized and SynchronizedServer response parameters will, however, display the correct state.

Note: The “show network ntp” command will display any avialable dynamic NTP servers and any previously configured static NTP servers, whether or not the NTP service is enabled. If the NTP service is disabled, only the server names are displayed. If the NTP service is enabled, the name and status for each NTP server will be displayed.

Table 4.61: Show Network Summary Response Parameters

Argument	Format	Description
PrimaryInterface	string	The primary network device enabled at start (e.g. 'eth:eth0' for Ethernet).
ActiveInterface	string	The currently active network device, such as 'eth:eth0' for Ethernet.
Hostname	string	The current hostname of the Reader.
connectionStatus	AdminUp Connected Disconnected	The connection status of the current active interface. The value is one of the following: <ul style="list-style-type: none"> • AdminUp: Interface is started but not yet connected. This state is temporary. • Connected: Interface is up and running. • Disconnected: Interface is down.
ipAddressMode	Dynamic Static	Indicates the current configuration of the network interface. Dynamic (using DHCP for IP configuration) or Status (using manual IP configuration).
ipAddress	IP address	Reports the current IP address assigned to the Reader. This value will not be reported if it is not currently assigned or the network is disconnected.

Argument	Format	Description
ipMask	IP address	Reports the current IP address mask assigned to the Reader. If not currently assigned or network disconnected, this value will not be reported.
gatewayAddress	IP address	Reports the current network gateway assigned to the Reader. This value will not be reported if it is not currently assigned or the network is disconnected.
broadcastAddress	IP address	Reports the current IP broadcast address assigned to the Reader. This value will not be reported if it is not currently assigned or the network is disconnected.

Table 4.62: Show Network IP Stat Response Parameters

Argument	Format	Description
ipForwarding	integer	See MIB-2 RFC 1213
ipDefaultTTL	integer	
ipInReceives	integer	
IpInHdrErrors	integer	
ipInAddrErrors	integer	
ipForwDatagrams	integer	
ipInUnknownProtos	integer	
ipInDiscards	integer	
ipInDelivers	integer	
ipOutRequests	integer	
ipOutDiscards	integer	
ipOutNoRoutes	integer	
ipReasmTimeout	Integer	
ipReasmReqds	integer	
IpReasmOKs	integer	
IpReasmFails	integer	
ipFragOKs	integer	
ipFragFails	integer	See MIB-2 RFC 1213
ipFragCreates	integer	

Argument	Format	Description
IpRoutingDiscards	integer	

Table 4.63: Show Network IP Summary Response Parameters

Argument	Format	Description
connectionStatus	AdminUp Connected Disconnected MismatchedModem Unauthorized	Current state of the network interface.
ipAddressMode	Dynamic Static	If configuration is currently dynamic, the dynamic values returned by DHCP are given. If a value is not currently set (such as the gateway address when LLA is in use,) the argument does not appear.
ipAddress	IP address	
IpMask	IP address	
gatewayAddress	IP address	
broadcastAddress	IP address	

Table: Show Network LLDP Response Parameters

Argument	Format	Description
ServiceEnabled	True False	Indicates whether or not the service will be started at boot time.
PoePlusRequired	True False	Indicates whether or not the reader requires PoE+ to ramp full power.
NegotiationState	Unknown PowerRequested PowerAllocated Error	The state of the reader/switch LLDP/CDP negotiation. When a PoE power injector or a switch that does not support LLDP is used, the state will remain Unknown. When an LLDP/CDP switch is used, after the switch responds, the state is PowerAllocated. See RequiredPowerAvailable to tell if power requirements can be met.
RequiredPowerAvailable	True False	After LLDP/CDP negotiation, this is True if the PoE+ switch can supply enough electrical power to the reader.

Argument	Format	Description
RequestedPower	integer	Power in milliwatts that the reader has requested from the Poe+ switch.
AllocatedPower	integer	Power in milliwatts that the switch has allocated to the PoE port.

The **show network lldp** command might only be available in Reader models prior to the Impinj R700 RAIN RFID Reader.

An example of successful LLDP/CDP negotiation with a PoE+ switch that can meet the reader's power requirements:

```
> show network lldp
Status='0,Success'
ServiceEnabled='True'
PoePlusRequired='True'
RequestedPower='20000'
AllocatedPower='25500'
NegotiationState='PowerAllocated'
RequiredPowerAvailable='True'
```

An example of the LLDP/CDP state for a PoE+ switch that has not replied to a power negotiation request or a power injector that does not support LLDP/CDP. In this state, the reader assumes that there is sufficient electrical power and will allow RFID operation.

```
> show network lldp
Status='0,Success'
ServiceEnabled='True'
PoePlusRequired='True'
RequestedPower='0'
AllocatedPower='0'
NegotiationState='Unknown'
RequiredPowerAvailable='AssumedTrue'
```

Example of LLDP/CDP status after a successful negotiation, but full power requirements cannot be met. In this state, an LLRP ROSpec will not be run and an LLRP error will result since the reader may reset as it increases RF power past the switch's capacity to supply power.

```
> show network lldp
Status='0,Success'
ServiceEnabled='True'
PoePlusRequired='True'
NegotiationState='PowerAllocated'
RequiredPowerAvailable='False'
RequestedPower='20000'
AllocatedPower='13000'
```

Reader products that do not require PoE+ do not use LLDP/CDP and the rshell command is unsupported:

```
> show network lldp
Status='7,Unsupported-Command'
```

The description for all arguments displayed in the following two tables are described in MIB-2 RFC 1213.

Table 4.64: Show Network TCP Response Parameters

Argument	Format	Description
tcpRtoAlgorithm	integer	See MIB-2 RFC 1213
tcpRtoMin	integer	
tcpRtoMax	integer	
tcpMaxConn	integer	
tcpActiveOpens	integer	
tcpPassiveOpens	integer	
tcpAttemptFails	integer	
tcpEstabResets	integer	
tcpCurrEstab	integer	
tcpInSegs	integer	
tcpOutSegs	integer	
tcpRetransSegs	integer	
tcpInErrs	integer	
tcpOutRsts	integer	

Table 4.65: Show Network UDP Response Parameters

Argument	Format	Description
udpInDatagrams	integer	See MIB-2 RFC 1213
udpNoPorts	integer	
udpInErrors	integer	
udpOutDatagrams	integer	

Table 4.66: Show Network Wlan Summary Response Parameters

The **show network wlan command** might only be available in Reader models prior to the Impinj R700 RAIN RFID Reader.

Argument	Format	Description
NetType	adhoc infra	The WiFi network type.
FeatureStatus	Disabled NotSupportedByHW NotSupportedOnPoE	Present if WLAN is not supported, in which case all other fields are absent. Disabled: Feature is explicitly disabled for whatever reason. Currently not supported. NotSupportedByHw: The hardware does not support WiFi feature. NotSupportedOnPoE: WiFi feature not supported when Reader is powered over Ethernet.
ConnectionStatus	AdminDown Searching Disconnected Connected	See the Show Network Summary Response Parameters table.
DeviceStatus	Absent Loading Loaded	Present only when connectionStatus is not Connected or Searching . Indicates the WiFi device status. Absent: The USB WiFi module is not plugged in. Loading: The WiFi driver is loading. Loaded: The WiFi driver is loaded.
SSID	String	The SSID of the currently connected network.
BSSID	MAC Address	The BSSID of the currently connected AP for infrastructure network. Or the (random) BSSID of the adhoc network initiator.
SignalLevel	<integer>dBm	The signal level of the currently connected AP.
MyMacAddress	MAC Address	The Mac address of the Reader's WiFi card.
PeerMacAddress	MAC Address	Present on in adhoc network. The MAC address of the i'th station that is connected on the ahoc network.

The **show network wlan config active/persistent** command shows the configuration that is currently active, or that is in persistent storage.

Table 4.67: Show Network Wlan Config Active/Persistent

Argument	Format	Description
NetType	adhoc infra	The active/persistent network type.
SSID	String	The active/persistent SSID.
Keymgmt	wpa-psk wpa-none none	The active/persistent Key management protocol.
Encrypt	wpa2 wpa none	The active/persistent encryption type.
PSK	String	The active/persistent preshared key shown as ***** if set, otherwise empty.

Table 4.68: Show Network Wlan Scanlist Response Parameters

Argument	Format	Description
NetType<i>	adhoc infra	The i'th BSSID's network type
BSSID<i>	MAC address	The BSSID of the i'th AP
SSID<i>	String	The SSID of the i'th AP.
Security<i>	String	The i'th AP's security settings, e.g. 'WPA2PSK/AES'
Frequency<i>	<integer>Mhz	The i'th AP's channel as represented by the MHz
SignalLevel<i>	<integer>dBm	The i'th AP's signal level.

Table 4.69: Show Network SFTP Response Parameters

Argument	Format	Description
Username	string	Shows '...' if the username is stored, otherwise empty ("")
Password	string	Shows '...' if the password is stored, otherwise empty ("")

4.3.4 Show RFID Menu

The **show rfid** menu contains commands to display RFID parameters and statistics. Submenu commands are shown in the following table.

Table 4.70: Show RFID Command Parameters

Command	Description
Stat	Display RFID statistics for the Reader.
Interface	Show enabled RFID Interface.
Llrp	Leads to submenu of LLRP status statistics.

Show RFID Stat

The **show rfid stat** command displays the RFID statistics for that Reader. See the following table for the complete stat response parameters.

Table 4.71: Show RFID Stat Response Parameters

Argument	Format	Description
LastStatisticReset	integer	The elapsed time [in seconds] since the RFID statistics were last reset.
ReaderOperational- Status	enabled disabled	Indicates whether RFID applications are running on the Reader.
ReaderAdministrative- Status	enabled	Desired status by administration is always enabled.
Antenna<n>- Administrative- Status	enabled	Desired status of antenna by administration - always enabled.

Argument	Format	Description
Antenna<n>- Operational- Status	enabled disabled unknown	Indicates if an antenna is physically connected to the Reader and operating properly. If no RFID operation has been performed, and no in-band LLRP checks of antenna status have been performed, the Reader will report unknown for this statistic. Once an RFID operation has occurred, or an in-band check is performed, the Reader will update this value. Enabled=connected antenna Disabled=disconnected from antenna. Note that accurate reports are only available on in-use antennas. Antennas currently not in use are not checked.
Antenna<n>Last- PowerLevel	integer	100 times the dBm setting of Antenna <n>.
Antenna<n>Last- NoiseLevel	integer	Always 0.
Antenna<n>- Energized- Time	integer	Time Antenna <n> has been powered, in milliseconds.
Antenna<n>Unique- InventoryCount	integer	Number of unique tags seen at Antenna <n>.

Argument	Format	Description
Antenna<n>Total-InventoryCount	integer	Total Inventory Count for Antenna <n>.
Antenna<n>Failed-InventoryCount	integer	Always 0.
Antenna<n>Read-Count	integer	Number of tags read at Antenna <n> that matched the configured filters.
Antenna<n>Failed-ReadCount	integer	Number of tags where a read was attempted at Antenna <n> because the tag matched the configured filters, but the read failed.
Antenna<n>-WriteCount	integer	Number of tags written at Antenna <n> that matched the configured filters.
Antenna<n>Failed-WriteCount	integer	Number of tags where a write was attempted at Antenna <n> because the tag matched the configured filters, but the write failed.
Antenna<n>-LockCount	integer	Number of tags locked at Antenna <n> that matched the configured filters.
Antenna<n>Failed-LockCount	integer	Number of tags where a lock was attempted at Antenna <n> because the tag matched the configured filters, but the lock failed.

Argument	Format	Description
Antenna<n>Kill- Count	integer	Number of tags killed at Antenna <n> that matched the configured filters.
Antenna<n>Failed- KillCount	integer	Number of tags where a kill was attempted at Antenna <n> because the tag matched the configured filters, but the kill failed.
Antenna<n>- EraseCount	integer	Number of tags erased at Antenna <n> that matched the configured filters.
Antenna<n>Failed- EraseCount	integer	Number of tags where a erase was attempted at Antenna <n> because the tag matched the configured filters, but the erase failed.

Show RFID Interface Command

The **show rfid interface** command displays the enabled RFID interface. Here is an example of successfully showing the RFID interface, changing it, and then showing the new interface.

```
> show rfid interface
Status='0,Success'
interface='Impinj LLRP Interface'
> config rfid interface rest
Status='0,Success'
> show rfid interface
Status='0,Success'
interface='Impinj RESTful Interface'
```

This command is only available on the R700 reader.

Show RFID LLRP Commands

The **show rfid llrp** command provides statistics on the LLRP interface and includes the subcommands listed in the following table.

Table 4.72: Show RFID LLRP Command Parameters

Command	Argument	Format	Description
accessspec	id	integer	Displays the XML text of a specified AccessSpec.
capabilities			Displays the XML text of the LLRP capabilities advertised by this Reader. Note: For readers that support more than one region, the capabilities may not be accurate if no region is selected.
config			Displays the XML text of the LLRP configuration.
inbound			Displays information about LLRP client-initiated connections.
outbound			Displays information about LLRP Reader-initiated connections.
region			Displays the LLRP region and Impinj sub-region at which the Reader is currently operating. Also will display sub-regulatory region information when configured by LLRP extensions.
rospec	id	integer	Displays the XML text of a specified ROSpec.
stat			Reports LLRP statistics.
summary			Displays a summary of the LLRP configuration and status.

Show RFID LLRP Outbound Command

This command displays information about LLRP Reader-initiated connections. Here is an example of successfully showing this information.

```
> show rfid llrp outbound
Status='0,Success'
LLRPOutboundTCPEnabled='True'
LLRPOutboundRetrySec='5'
LLRPOutboundTimeoutSec='2'
LLRPOutboundSecurity='None'
LLRPOutboundTCPServer1=""
LLRPOutboundTCPServer2=""
```

```

LLRPOutboundTCPServer3="
LLRPOutboundTCPServer4="
LLRPOutboundTCPServer5="
>

```

4.3.5 Show SNMP Menu

The **show snmp** menu displays information about the SNMP configuration. The following table provides a list of the available **show snmp** subcommands.

Table 4.73: Show SNMP Command Parameters

Command	Description
all	Displays all of the the SNMP settings.
summary	Displays summary of generic SNMP settings.
epcg	Displays EPCG RM MIB specific settings.

The response parameters for **show snmp summary** and for **show snmp epcg** are shown in the following two tables. The response parameters for **show snmp all** is a concatenation of the summary and **epcg** response parameters.

Table 4.74: Show SNMP Summary Response Parameters

Argument	Format	Description
SnmService	Enabled Disabled	The status of the SNMP service.
ROCommunity	string	The value of the read-only community string.
RWCommunity	string	The value of the read-write community string.
TrapCommunity	string	The value of the trap community string.
WriteEnabled	True False	Indicates whether SNMP writes are enabled or disabled.
TrapService	Enabled Disabled	The status of the SNMP trap service.
Sink	string	The hostname or IP address that will receive SNMP traps.
Sink2	string	Additional hostname or IP address to receive SNMP traps.
Sink3	string	Additional hostname or IP address to receive SNMP traps.
Sink4	string	Additional hostname or IP address to receive SNMP traps.

Argument	Format	Description
Port	string	The UDP port that SNMP traps will be sent to.

Table 4.75: Show SNMP EPCG Response Parameters

Argument	Format	Description
EpcgRmMib-Revision	string	The Epcglobal Reader management MIB revision, example. 200703080000Z.
EpcgRdrDev-Description	string	Reader description: The same value that is reported for SNMP system description.
EpcgRdrDevRole	string	The value of the configured device role.
EpcgNotifChan-Name1	string	The name of notification channel 1. Always the LLRP Client.
EpcgNotifChan-Name2	string	The name of notification channel 2. Always the LLRP Reader.
EpcgRdrDevOper-StateEnable	string	Indicates whether Reader operation state change notifications are enabled. Always False .
EpcgRdrDevOperNotif-StateLevel	string	The severity level for Reader operation state change notifications. Always Error .
EpcgReadPointOper-StateNotifyEnable	string	Indicates whether read point operation state notifications are enabled. Always False .
EpcgReadPointOper-NotifyStateLevel	string	The severity level for read point operation state change notifications. Always Error .
EpcgSrcOper-StatusNotifEnable	string	Indicates whether source state change notifications are enabled. Always False .
EpcgSrcOper-StatusNotifyLevel	string	The severity level for source state change notifications. Always Error .
EpcgNotifChan-OperNotifEnable	string	Indicates whether notification channel operation state change notifications are enabled. Always False .
EpcgNotifChan-OperNotifLevel	string	The severity level for notification channel operation state change notifications. Always Error .

4.3.6 Show System Menu

The **show system** menu displays information about the state of the Reader. The following table provides a list of the available **show system** subcommands. The next four tables after that summarize the respective response parameters.

Table 4.76: Show System Command Parameters

Command	Description
cpu	Displays statistics regarding platform memory usage and available application space
platform	Displays generic platform statistics
summary	Displays a summary of system info
region	Displays alternative regions options (if any)
power	Display powersource info (LLDP status)

Table 4.77: Show System CPU Response Parameters

Argument	Format	Description
TotalMemory	integer	Total available RAM in bytes
FreeMemory	integer	Total free RAM in bytes
CpuUtilization	integer	CPU utilization in percent
TotalConfiguration-StorageSpace	integer	Total configuration/persistent partition space in bytes
FreeConfiguration-StorageSpace	integer	Free configuration/persistent partition space in bytes
TotalApplication-StorageSpace	integer	Total application partition space in bytes
FreeApplication-StorageSpace	integer	Free application partition space in bytes

Table 4.78: Show System Platform Response Parameters

Argument	Format	Description
BootEnv- Version	integer	Internal 'Boot Environment' data version
Hardware- Version	string	Returns the hardware version information for the Reader and internal hardware.
IntHardware- Version		
SerialNumber	string	Returns the Reader's hardware serial number for thr Reader and internal hardware.
IntSerialNumber		
MACAddress	string	MAC address of the unit's Ethernet port.
HLAVersion	string	Returns the High Level Assembly (HLA) information for the Reader.

Argument	Format	Description
RegionsValid	integer[,integer,...]	Indicates the numerical values of the regions supported on this hardware.
FeaturesValid	integer[,integer,...]	Indicates features enabled on this hardware.
BIOSVersion	string	Returns the version information for the Reader BIOS.
PTN	integer.integer	Product Type Number This is used to differentiate Reader models.
UptimeSeconds	integer	Time since last reboot in seconds.
BootStatus	integer	Bootloader status. This indicates various boot errors detected by the boot loader.
BootReason	Cold Processor Reboot External Watchdog External Watchdog Fallback	The reason for the last reboot. A Cold reboot occurs when power is first applied to the Reader. Processor / Reboot occurs when software causes a reboot. External Watchdogs are the result of the Reader being reset by the embedded watchdog feature. An External Watchdog Fallback occurs after repeated watchdog resets and an automatic rollback of the image (if available).
PowerFailTime	integer	Linux time of last power fail expressed in seconds. Only defined for the first boot following a power failure.
ActivePowerSource	PoE jack	Indicates power source as either Power over Ethernet (PoE) or power jack.

Table 4.79: Show System Summary Response Parameters

Argument	Format	Description
SysDesc	string	The system description. Defaults to model name of the Reader.
SysContact	string	The system contact information. Defaults to 'unknown'.
SysName	string	The system name. Defaults to hostname of the Reader.
SysLocation	string	The system location. Defaults to 'unknown'.
SysTime	string	The current time on the Reader in UTC.

Table 4.80: Show System Region Response Parameters

Argument	Format	Description
Operating- Region	integer	Current operating region number.
Selectable- Regions	integer[,integer,...]	Available operating region numbers.
Selectable- Region<n>	integer,string	List of the available operating region numbers along with a short descriptive string. <n> starts at zero.

Table 4.81: Show System Power Response Parameters

Argument	Format	Description
ServiceEnabled	True False	Indicates whether or not the service will be started at boot time.
NegotiationTimeout	integer	The maximum time to negotiate the power source, in milliseconds.
PoePlusRequired	True False	Indicates whether or not the reader requires PoE+ to ramp full power.
NegotiationState	Unknown PowerRequested PowerAllocated Error	The state of the reader/switch LLDP/CDP negotiation. When a PoE power injector or a switch that does not support LLDP is used, the state will remain Unknown. When an LLDP/CDP switch is used, after the switch responds, the state is PowerAllocated. See RequiredPowerAvailable to tell if power requirements can be met.
RequiredPowerAvailable	True False	After LLDP/CDP negotiation, True if the PoE+ switch can supply enough electrical power to the reader.
RequestedPower	integer	Power in milliwatts that the reader has requested from the PoE+ switch.
AllocatedPower	integer	Power in milliwatts that the switch has allocated to the PoE port.

Argument	Format	Description
PowerSource	PoE PoE+ Auto	The power source (PoE or Power over Ethernet, PoE plus, or automatic negotiation).

The **show system power** command might only be available in the Impinj R700 RAIN RFID Reader and later models.

An example of successful LLDP/CDP negotiation with a PoE+ switch that can meet the reader's power requirements:

```
> show system power
Status='0,Success'
ServiceEnabled='True'
NegotiationTimeout='20000'
PoePlusRequired='True'
RequestedPower='20000'
AllocatedPower='25500'
NegotiationState='PowerAllocated'
RequiredPowerAvailable='True'
PowerSource='auto (PoE+)'
```

An example of the LLDP/CDP state for a PoE+ switch that has not replied to a power negotiation request or a power injector that does not support LLDP/CDP. In this state, the reader assumes that there is sufficient electrical power and will allow RFID operation.

```
> show system power
Status='0,Success'
ServiceEnabled='True'
NegotiationTimeout='20000'
PoePlusRequired='True'
RequestedPower='0'
AllocatedPower='0'
NegotiationState='Unknown'
RequiredPowerAvailable='AssumedTrue'
PowerSource='auto (PoE)'
```

Example of LLDP/CDP status after a successful negotiation, but full power requirements cannot be met. In this state, an LLRP ROSpec will not be run and an LLRP error will result since the reader may reset as it increases RF power past the switch's capacity to supply power.

```
> show system power
Status='0,Success'
ServiceEnabled='True'
NegotiationTimeout='20000'
PoePlusRequired='True'
NegotiationState='PowerAllocated'
RequiredPowerAvailable='False'
RequestedPower='20000'
AllocatedPower='13000'
PowerSource='auto (PoE)'
```

Reader products that do not require PoE+ do not use LLDP/CDP and the rshell command is unsupported:

```
> show system power
Status='7,Unsupported-Command'
```

4.3.7 Show Feature Menu

The **show feature** menu displays information regarding features enabled on the Reader. The following table provides a list of the available parameters. The table after that summarizes the respective response parameters for the Antenna Hub feature. The **show feature all** command includes all the feature response parameters defined in this section.

Table 4.82: Show Feature Command Parameters

Command	Description
all	Display information for all defined features.
stp2	Display information for the STP2 feature group.
anthub	Display information for the Antenna Hub feature.

Table 4.83: Show Feature Anthub Response Parameters

Argument	Format	Description
anthubKey-Status	Activated Deactivated	R120 and R420 always display Activated, All others display Deactivated.
anthubStatus	Enabled Disabled	Operational status of the Antenna Hub feature.

4.3.8 Show Anthub Command

The **show anthub** command has a parameter as shown in the following table.

Table 4.84: Show Anthub Command Parameters

Command	Description
summary	Display a summary of Anthub info.

The **show anthub summary** command has a response as shown in the following table.

Table 4.85: Show Anthub Summary Response

Argument	Format	Description
FeatureStatus	Enabled Disabled	Displays whether anthub mode is configured as enabled or disabled.
AntennaHub[n] ConnectionStatus	Unknown Disconnected Connected	Indicates if an Antenna Hub was detected at boot up. ‘Unknown’ indicates that the feature was disabled at boot up. Note that this field is not dynamically updated.
AntennaHub[n] Fault	None RF power RF power seen on Hub n Not initialized Serial	
AntennaHub[n] FWVersion	string	Displays the version of firmware that is running on the Antenna Hub microcontroller.
AntennaHub[n] PCBVersion	string	Displays the Antenna Hub’s hardware version.
AntennaHub[n] SerialNumber	string	Displays the Antenna Hub’s serial number.

5 Revision History

Date	Revision	Comments
04/02/2009	1.0	Initial release
04/20/2009	1.1	Updated for first release
08/27/2009	4.2	Added SNMP support Added mDNS and LLA support Updated Upgrade error message for a non-matching hardware version between the image file and the Reader. Clarified LLRP connection management Added comment for “show image summary” that secondary parameters/values are only shown if the secondary image is valid. Corrected strings to match RShell counterparts.
02/24/2010	4.4	Finalized for release Added DNS-SD support Updated status code table with new values
03/05/2010	4.4	Added cellular and GPS support.
03/31/2010	4.4	Added “show network dnssd” to show http status
10/27/2010	4.6	Updates for Octane 4.6 release

Date	Revision	Comments
4/25/2011	4.8	Updates for Octane 4.8 release Added: Config System Region Command Added: Config Image RemoveCAP Command Added: Config Feature Command Added: Show System Region Command Added: Show Feature Command Added: Warning regarding changing region Added: Configuration for wlan Other minor clarifications
5/20/2012	4.10	Updates for Octane 4.10 release Added: Antenna Hub feature
12/16/2014	5.2	Updates for Octane 5.2 release
5/29/2015	5.4	Updates for Octane 5.4 release Added: portsecurity feature for wire 802.1x configuration support Added: SFTP as a supported protocol and related commands to set credentials
9/2/2015	5.6	Updates for Octane 5.6 release Added: SNMP trap and V3 support
12/21/2015	5.6.2	Updates for Octane 5.6.2 release
10/10/2016	5.8	Updates for Octane 5.8 release, including
11/29/2016	5.10	Updates for Octane 5.10 release Modified: zeroconf related RShell Commands Modified: config network ip command requires a reboot
2/21/2017	5.12	Updates for Octane 5.12 release Modified: allowed syslog servers. Modified: Document the NTP service before changing NTP set

Date	Revision	Comments
5/15/2017	5.12	Updated for R120 support. Removed spec of antennas with or without Antenna Hub command.
1/30/2020	7.00	Updated for Octane 7.00 release and R70. Supplemented lldp commands with power
5/15/2020	7.1	Updated for Octane 7.1 release. Included and show/config rfid interface.

6 Notices

Copyright © 2020, Impinj, Inc. All rights reserved.

Impinj gives no representation or warranty, express or implied, for accuracy or reliability of information in this document. Impinj reserves the right to change its products and services and this information at any time without notice.

EXCEPT AS PROVIDED IN IMPINJ'S TERMS AND CONDITIONS OF SALE (OR AS OTHERWISE AGREED IN A VALID WRITTEN INDIVIDUAL AGREEMENT WITH IMPINJ), IMPINJ ASSUMES NO LIABILITY WHATSOEVER AND IMPINJ DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY, RELATED TO SALE AND/OR USE OF IMPINJ PRODUCTS INCLUDING LIABILITY OR WARRANTIES RELATING TO FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, OR INFRINGEMENT.

NO LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE, TO ANY PATENT, COPYRIGHT, MASK WORK RIGHT, OR OTHER INTELLECTUAL PROPERTY RIGHT IS GRANTED BY THIS DOCUMENT.

Impinj assumes no liability for applications assistance or customer product design. Customers should provide adequate design and operating safeguards to minimize risks.

Impinj products are not designed, warranted or authorized for use in any product or application where a malfunction may reasonably be expected to cause personal injury or death or property or environmental damage ("hazardous uses") or for use in automotive environments. Customers must indemnify Impinj against any damages arising out of the use of Impinj products in any hazardous or automotive uses.

Impinj, GrandPrix™, Indy®, Monza®, Octane™, QT®, Speedway®, STP™, True3D™, xArray®, and xSpan® are trademarks or registered trademarks of Impinj, Inc. All other product or service names are trademarks of their respective companies.

These products may be covered by one or more U.S. patents. See <http://www.impinj.com/patents> for details.

For more information, contact support@impinj.com